



Änderungen vorbehalten,
auch ohne Anknüpfung.
© dnt '93

- NOTES :
- 1) ALL RESISTANCE VALUES ARE INDICATED IN "OHM" (1K = 1000 OHM , 1M = 1000 000)
 - 2) ALL CAPACITANCE VALUES ARE INDICATED IN "UF" (1n = .001 UF , 10p = .001 UF)
 - 3) 04, 06A : KT5091 (7) , 015, 13, 20 : KT4087 (7) , 015, 17, 20, 30 : KT4088 (7) , 05 TO 13, 14, 16, 21, 22, 26, 28, 29, 32, 34 : KT4089 (7) , 016 : KT4086 (7) .