

HR-2800

28 MHZ AM-FM
AMATEUR RADIO HF TRANSCEIVER


Service Manual





Downloaded from www.cbradio.nl

INTEK®



DC-DC Converter Diagram





ESP Comander Diagram - CTCSS Diagram




PCB - Main Board & CPU Board




PCB - Main Board & CPU Board




Diagram



Block Diagram



Block Diagram



INTEK[®]