

Known Models: Browning Brownie
Cobra 85
Tram XL

	RX & TX	RX & TX	TX Only	RX Only
	"A"	"B"	"C"	"D"
Ch. 1 (26.965)	11.705	7.4600	7.800	7.345
Ch. 2 (26.975)	"	7.4700	"	"
Ch. 3 (26.985)	"	7.4800	"	"
Ch. 4 (27.005)	"	7.5000	"	"

Ch. 5 (27.015)	11.755	7.4600	7.800	7.345
Ch. 6 (27.025)	"	7.4700	"	"
Ch. 7 (27.035)	"	7.4800	"	"
Ch. 8 (27.055)	"	7.5000	"	"

Ch. 9 (27.065)	11.805	7.4600	7.800	7.345
Ch.10 (27.075)	"	7.4700	"	"
Ch.11 (27.085)	"	7.4800	"	"
Ch.12 (27.105)	"	7.5000	"	"

	RX & TX	RX & TX	TX Only	RX Only
	"A"	"B"	"C"	"D"
Ch.13 (27.115)	11.855	7.4600	7.800	7.345
Ch.14 (27.125)	"	7.4700	"	"
Ch.15 (27.135)	"	7.4800	"	"
Ch.16 (27.155)	"	7.5000	"	"

Ch.17 (27.165)	11.905	7.4600	7.800	7.345
Ch.18 (27.175)	"	7.4700	"	"
Ch.19 (27.185)	"	7.4800	"	"
Ch.20 (27.205)	"	7.5000	"	"

Ch.21 (27.215)	11.955	7.4600	7.800	7.345
Ch.22 (27.225)	"	7.4700	"	"
Ch.23 (27.255)	"	7.5000	"	"

Synthesis: "A" + "B" + "C" = direct TX carrier frequency;
"A" + "B" + "D" = RX frequency (offset lower by 455 KHz)

Example: For Ch.1, [11.705 MHz + 7.460 MHz + 7.800 MHz] = 26.965 MHz. The TX Oscillator when present (like this type of chassis) is always equal to the first IF, in this case 7.800 MHz.

Compliments of:

CBC INTERNATIONAL · P.O. BOX 30655 · TUCSON AZ 85751 U.S.A.
TEL/FAX: 888-I-FIX-CBs (1-888-434-9227), (520) 298-7980 · Internet: www.cbcintl.com · Email: info@cbcintl.com